



Model:  
PRS McCarty TCI Lefty





Note: Pickup shape is just for reference.  
All pickups using this diagram shall be oriented in this manner.


Bass (Neck) Pickup




Treble (Bridge) Pickup



3-way Pickup Selector Switch:



Push-pull Tone Pot:



Operating Instructions

- 3-way toggle pickup switch:
  - Position 1 (down) - Treble Pickup
  - Position 2 - Treble and Bass Pickups
  - Position 3 (up) - Bass Pickup
- Push-Pull Tone Pot:
  - Down - Humbucker Mode
  - Up - Single Coil Mode