





Model:  
 PRS S2 Vela  
 PRS S2 Vela Semi-Hollow  
 PRS S2 Vela Satin  
 PRS S2 Vela Semi-Hollow Satin


Note Pickup shape is just for reference.  
 All pickups using this diagram  
 shall be oriented in this manner.



Bridge Push-pull Tone Pot:



3-way Pickup Selector Switch:



Operating Instructions

3-way Toggle Pickup Switch:  
 Position 1 (down) - Treble Pickup  
 Position 2 - Treble and Bass Pickups  
 Position 3 (up) - Bass Pickup  
 Push-Pull Tone Pot (treble pickup only):  
 Down - Humbucker Mode  
 Up - Single Coil Mode