


Model:
PRS DGT

Note Pickup shape is just for reference.
All pickups using this diagram
shall be oriented in this manner.



Bass (Neck) Pickup

South

North


Treble (Bridge) Pickup

South


North

Bridge location

Push-pull Tone Pot:



3-way Pickup Selector Switch:



Operating Instructions

3-way toggle pickup switch:

Position 1 (down) - Treble Pickup

Position 2 - Treble and Bass Pickups

Position 3 (up) - Bass Pickup

Push-Pull Tone Pot:

Down - Humbucker Mode

Up - Single Coil Mode