




Model:
PRS McCarty


Note: Pickup shape is just for reference.
All pickups using this diagram
shall be oriented in this manner.



Push-pull Tone Pot:



3-way Pickup Selector Switch:



Operating Instructions

3-way toggle pickup switch:

- Position 1 (down) - Treble Pickup
- Position 2 - Treble and Bass Pickups
- Position 3 (up) - Bass Pickup

Push-Pull Tone Pot:

- Down - Humbucker Mode
- Up - Single Coil Mode