


Used on these models:  
PRS SE NF53



Operating Instructions

3-Way Blade Switch

- Position 1 (down) - Treble Pickup
- Position 2 (middle) - Treble and Bass Pickups
- Position 3 (up) - Bass Pickup