





Model:
 PRS Tekton
 PRS Tekton T
 PRS Tekton "Floyd"
 PRS Tekton SVN

Note: Pickup shape is just for reference.
 All pickups using this diagram
 shall be oriented in this manner.




Bridge location

3-way Pickup Selector Switch:



Bridge Push-pull Tone Pot:



Bass Pickup Wires:	Treble Pickup Wires:
A - Green	E - Green
B - Red	F - Red
C - White	G - White
D - Black	H - Black

Operating Instructions

3-way Toggle Pickup Switch:

Position 1 (down) - Treble Pickup
 Position 2 - Treble and Bass Pickups
 Position 3 (up) - Bass Pickup

Push-Pull Tone Pot:

Down - Humbucker Mode
 Up - Single Coil Mode